


HS2LED/HS2ICN(P)(RF)x/HS2LCD(P)(RF)x v1.3 安装说明书



警告：请参阅 PowerSeries Neo 参考手册，了解有关产品使用和功能限制的信息以及制造商责任限制的信息。

注意：这些说明书必须结合与此设备相关的主机系统安装手册一起使用。本安装手册适用于以下型号：HS2LED、HS2ICN、HS2ICNP、HS2ICNRF、HS2ICNRFPP、HS2LCD、HS2LCDP、HS2LCDRFP、HS2LCDRFPx、HS2LCDRFPx x 9 时，系统操作频率为 912.919MHz，x 8 时，系统操作频率为 868MHz；x 4 时，系统操作频率为 433MHz。根据针对 II 类 2 级设备的 EN50131-2:2006 + A1:2009、EN50131-3:2009 标准，HS2LED、HS2LCD(P)、HS2ICN(P)、HS2LCDRFP 和 HS2ICNRF 产品符合 TeleTrafic 认证。



安装说明书

HS2LED/HS2ICN(P)(RF)x/HS2LCD(P)(RF)x 键盘兼容 PowerSeries Neo HS2016/32/64、HS2016-4 和 HS2128 主机。RF 键盘组合了无线收发器和各自的 HS2 键盘。

规格

- 温度范围：-10°C 至 +55°C (14°F 至 131°F)
- 湿度（最大值）：相对湿度 93%，无冷凝
- 塑料外壳防护等级：IP30、IPK4
- 电压额定值：13.8Vdc 额定电压（兼容主机提供的电源）
- 5 个可编解码功能
- S2LED/HS2ICN(P)/HS2LCD(P)/HS2ICNRF(P)/HS2LCDRFP(P) 电流消耗：55mA（最小值）/105mA（最大值）
- 壁挂式防拆装置
- 5 个可编解码功能
- 就绪灯（绿灯）、布防（红灯）、故障（黄灯）和 AC（绿灯）
- 尺寸（长 x 宽 x 深）：168mm x 122mm x 20 mm
- 重量：260g
- 低频传感器
- 频率：433 MHz (HS2ICNRF/HS2LCDRFP)
- 668 MHz (HS2ICNRF/HS2LCDRFP)
- 912.919MHz (HS2ICNRF/HS2LCDRFP)
- 高达 128 个无线防区

* 此防区不能设置为防拆类型或 24 小时类型。

注意：键盘不包含可维修的部件。

拆箱

键盘包装包括以下内容：

- HS2LED/HS2ICN(RF)/LCD(RF) HS2ICN(RF)/IP/LCD(RF)/P

- 1 个键盘
- 1 个光盘
- 4 个安装螺丝
- 2 个终端 (EOL) 电阻器
- 键盘室内门标签
- 1 个防拆开关
- 安装说明书
- 迷你感应 (prox) 标签 (MPT)

布线

- 为每个装置布线前，请确保连接主机的所有电源（AC 交直流和电池）都是断开的。
- 将主机的红、黄、黄绿和四根 Corbus 电线与键盘端子相连接。请参考此指南：

- 如果此防区设置为输入，门磁等设备可以连接到此防区的“P/Z”端子。这样无需为这些设备将线路引回主机。要连接防区，将设备的一条接线连接到“P/Z”端子，其他接线连接到 B（黑色）端子。对于供电设备，将红线连接到 R（正极）端子，黑线连接到 G（负极）端子。如果使用有线门磁控制，请按照 PowerSeries Neo 参考手册中介绍的一个配置连接防区。

注意：对于 ULULC 安装，防区输入是受监控的类型（SEAU/DEOL）。监控电阻器为 5600Ω。如果没有使用 EOL 监控，EOL 设备所需的最大距离有英尺。只能使用符合 ULULC 认证的防区。

注意：与此输入触点连接的每个初始装置不用用于医疗或消防应用。

- 如果“P/Z”端子设置为输出，正极供电电压和“P/Z”端子之间的任何电压，可在两个端子之间连接小型继电器（如 DSC 型号 RM-1 或 RM-2）或报警器或其他 DC 供电的设备。

通电

一旦完成所有接线，至少使用两个螺丝就可以将此设备固定在木板上，然后将主机通电。

- 连接电源导线与电池。
- 检查有关主机电源规格的信息，请参见 PowerSeries Neo 的参考手册。

设置键盘

- 按 [M] 安装人员代码。
- 使用 [←] 键浏览菜单或输入分段号码直接到具体部分。

设置包含在每段之间或通过填写数据字段来切换选项。按下键盘上相应的数字，可启用或关闭切换选项。例如，要启用切换选项 1 和 4，按 [1] 和 [4] 键，显示所有启用的选项（见图 1）。

- 要输入数据，使用 [←] 键选择数字，然后按键盘按输入数字 / 字母。

注意：一旦注册的设备数目达到了最大值，就会发出错误提示音并显示警告消息。

设置键盘 (仅 LCD 版本)

- 按 [M] 安装人员代码。
- 按 [←] 和使用 [←] 键滚动至“防区标签”，并再次按 [M]。显示第一防区。另外，输入 [000][00]。

3. 使用 [←] 键滚动到要设置的防区标签，并按 [M] 或输入防区编号（如 001 表示防区 01）

4. 使用 [←] 键滚动至所需的字符位置。

5. 输入对应于字符的次数，直到显示所需的字符（见下表）。例如，按“2”键 3 次可输入字母“F”。按“2”键 4 次可输入数字“2”。按 [M]，然后滚动到“保存”，再次按下 [M] 保存更改。

[1]-[A, B, C, 2]	[0]-[M, N, O, 5]	[0]-[Y, Z, 9, 0]
[2]-[D, E, F, 2]	[0]-[P, Q, R, 6]	[0]-[空格]
[3]-[G, H, I, 3]	[0]-[S, T, V, 7]	[0]-[选择]
[4]-[J, K, L, 4]	[0]-[W, X, 8]	[0]-[两-逻辑]

标签。要删除字符，请使用 [←] 键将光标移动到字符下，并按 [0]。如果按除 [←] 之外的任何键，则再按 [0]，光标从一个空格移动到其右侧，然后删除此字符。

CHANGE CASE：从下一个字母输入开始，将大写字母 (A, B, C...) 和小写字母 (a, b, c...) 之间进行切换。

ASCII ENTRY：用来输入二进制。无效输入范围从 000 至 255。使用 [←] 键滚动到显示数字输入 000-255 的 3 位数。按 [M] 键将数字输入到标签。

CLEAR TO END：清除从光标所在位置的字符到末尾显示的显示内容。

- CLEAR DISPLAY**：清除整个标签。
- 从第 2 步开始继续操作，直到设置完所有标签。

标签 LCD 保存

当安装标签时，标签库是常用词汇的数据库。可按需合并单个词汇（例如前 + 门）。每行最多可显示 14 个字符。如果一行显示不下一个词，则向右滚动光标至下一行第一个字符处再添加该词。

使用 [M] 安装人员代码 [000][00]1。

按 [M] 安装人员代码 [0] 设置，或使用 [←] 键滚动至防区标签，然后按 [M]。为此防区设置当前的标签名称。

- 按 [M] 打开菜单。
- 再次按 [M] 选择“Word Entry”选项。
- 输入一个词所对应的 3 位二进制码（见“词库”或使用 [←] 键查看词库中间。
- 按 [M] 保存。
- 要添加另一个词，请重复步骤 3 之前的步骤。
- 要删除空格，请按向右导航键 [→]。
- 按 [M] 保存。
- 按 [M] 保存当前标签并退出。

广播 LCD 保存

如果系统中存在多个 LCD 键盘，确认更改后，将为所有其他 LCD 键盘播放一个键盘上所设置的更改。

更改亮度 / 对比度 / 报警器

- 按 [M] 主菜单。
- 使用 [←] 键滚动进行亮度控制、对比度控制或报警器控制。
- 按 [M] 保存。

亮度 LED 亮度控制：提供 15 个背景灯亮度级别。

[012] 本地 PGM 输出脉冲激活时间

分钟 (00-99) 秒钟 (00-99)

[021] 第一个键盘选项

默认	选项	开	关
开	1	启用消防键	关闭消防键
开	2	启用医疗键	关闭医疗键
开	3	启用紧急键	关闭紧急键
开	4	设置时显示门禁密码	设置门禁密码时显示 X

[022] 第二个键盘选项

默认	选项	开	关
开	1	本地时钟显示	本地时钟显示
关	2	本地时钟显示 24 小时	时钟显示上午 / 下午
开	3	自动报警内存滚动开	自动报警内存滚动关
开	4	以备将来使用	以备将来使用
开	5	启用电源指示灯	关闭电源指示灯
开	6	电源指示灯指示 AC 存在	电源指示灯指示 AC 存在
开	7	布防时不显示报警	布防时不显示报警
开	8	自动滚动撤防防区开	自动滚动撤防防区关

[023] 第三个键盘选项

默认	选项	开	关
关	1	布防指示灯省电模式	睡眠模式时布防指示灯
开	2	键盘状态显示留守布防	键盘状态显示留守 / 离开布防
关	3	第 5 个端子是键盘 PGM 输出	第 5 个端子是键盘防区输入
开	4	感应标签将进行布防 / 撤防	感应标签不进行布防 / 撤防
关	7	本地显示温度	无本地显示温度
关	8	低温警告已启用	低温警告已关闭

[030] 已下载 LCD 选项

第 22 页，选项 [1] 本地时钟显示必须启用。

[031] 已下载 LCD 消息时长

默认值：000（有效输入范围为 000-255，000=无限消息显示）

此数字为永久删除已下载消息前必须清除此消息的选项。按任意键可清除此消息。

[041] 室内无线防区分配

默认值：000（有效输入范围为 000-128）

[042] 室外温度防区分配

默认值：000（有效输入范围为 000-128）

感应 (Prox) 标签支持 (HS2ICNRF/HS2LCDRFP/HS2LCD)

感应标签可执行任何通常需用户输入密码或激活后可执行的键功能。

通过感应标签阅读器 (或) 或键盘液晶左侧感应标签。

分配感应标签

- 按 [M] 主菜单 / 监控人员密码。
- 输入 4 位用户 ID 号码。
- 按下 2。
- 通过键盘标签阅读器附近的注册标签。

编程感应标签

编程感应标签，选择以前提到的用户，刷关联的感应标签。警告系统识别此标签，出现提示时，按 [M] 删除。

LED 光源

在 HS2ICNPF/HS2ICNRF/HS2LCD 键盘上，蓝色 LED 光源表示设备即将到来。

当感应正在读取有效的感应标签时，LED 光源闪烁三次。

如果感应标签支持 LED 光源，LED 光源会发出错误提示音。

LED 光源的亮度在 [M] 菜单中是可调的。当修改背景光亮度时，也会相应更改 LED 光源的亮度。

正在下载

HS2LCDRFP/HS2ICNRF 产品可以通过 DLSV 来进行设置。这可以自动检测键盘类型并下载相应的设置。

无线设备设置和编程 (HS2ICNRF(P)x/HS2LCDRFP(P)x)

本节介绍如何在报警主机上注册和设置无线装置，如触点、运动传感器和报警器等。

[80][00] 注册无线设备

- 一旦在报警主机上安装并注册了 HSM2HOST，便可以使用以下方式注册无线设备：输入安装程序设置段号 [804][00]。
- 出现提示后，激活设备（参见设备安装）立即注册或输入设备 ID 号。执行后者可预先注册设备，然后可在各区域中注册。

报警主机决定正在注册的设备类型，并显示相应的设置选项。

表 4：无线设备选项

设备类型	设置选项
防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 5：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 6：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 7：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 8：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 9：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 10：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 11：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 12：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 13：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 14：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 15：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 16：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 17：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 18：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 19：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 20：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备。
- 重复上述的步骤，直到注册了所有无线设备。

表 21：无线设备选项

防区	(01) 防区类型 (02) 子系统分配 (03) 防区标签
无线键	(01) 子系统分配 (02) 用户标签
报警器	(01) 子系统分配 (02) 报警器标签
中继器	(01) 中继器标签

- 使用滚动键或键入对应号码来选择选项。
- 滚动浏览可用的选项，并根据情况键入号码或输入文本。
- 按 [M] 接受并移动到下一选项。
- 一旦配置所有选项，系统就会提示您注册下一设备

HS2LED/HS2ICON(P)(RF)/X/HS2LCD(RF)(P)(X) V1.3 Installation Instructions



WARNING: Please refer to the System Installation Manual for information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer. NOTE: These instructions shall be used in conjunction with the system Installation Manual of the Control Panel with which this equipment is intended to be used.



Introduction

The HS2LED/HS2ICON(P)(RF)/X/HS2LCD(RF)(P)(X) keypads are compatible with the PowerSeries Neo HS2106/2104, HS2105/2104* and HS2128 panels. The RF keypads combine a wireless transmitter with the respective HS2 keypad.

Specifications

- Temperature range: -10°C to +55°C (14°F to 131°F); ULULIC: 0°C to +40°C (32°F to 102°F)
- Humidity (MAX): 93%RH, non-condensing
- Plastic enclosure protection degree: IP30, IK04
- Voltage rating: 13.8Vdc nominal (power provided by the compatible control panel)
- Connects to control panel Corbus via 4 wires
- Configurable zone input or PGM output*
- HS2LED/HS2ICON(P)(HS2LCD)(P)(HS2ICNRF)(P)/HS2LCD(RF)(P) Current draw: 55mA(min)/105mA(Max)
- Wall-mount tamper
- 3 programmable function keys
- Ready (Green LED), Armed (Red LED), Trouble (Yellow LED), AC (Green LED)
- Dimensions (L x W x D): 168mm x 122mm x 20 mm
- Weight: 260g
- Low temperature sensor
- Frequency: 433 MHz (HS2ICNRF/HS2LCD(RF)/HS2LED/HS2ICON(P)(HS2LCD)(P)(HS2ICNRF)(P)/HS2LCD(RF)(P))
- Up to 128 wireless devices

Zone not to be programmed as Fire type or 24h type. No PGM outputs on conventional parts.

NOTE: Only models operating in the band 912-919 MHz are ULULIC listed.

Unpack

- The unpack package includes the following:
- HS2LED/HS2ICON(P)(RF)/X/HS2LCD(RF)(P)(X) keypad
 - 1 mounting screws
 - 2 end-of-line resistors
 - Keypad inner door labels
 - 1 tamper switch
 - Installation Instructions
 - 1 tamper switch
 - Installation Instructions
 - 1 tamper switch (prox tag (MPT))

control panel for the device. To connect the zone, run one wire from the device to the terminal and the other wire from the device to the B (Black) terminal. For powered devices, run the red wire to the R (positive) terminal and the black wire to the B (negative) terminal. When using end-of-line supervision, connect the zone according to one of the configurations described in the PowerSeries Neo Reference manual.

NOTE: For ULULIC installations, the zone input is a supervised input (EOL/DIR). The supervision exists at 500KΩ. If no EOL supervision is used, there is a three foot maximum distance required for the connected device. Use only in conjunction with ULULIC listed devices.

NOTE: This initiating device connected to this input contact is not to be used for medical or fire applications.

3. If the P/Z terminal is programmed as an output, a small relay (such as DSC model RM-1 or RM-2) or buzzer or other DC operated device may be connected between the positive supply voltage and the P/Z terminal (max load is 50mA).

NOTE: For ULULIC-listed installations, use ULULIC listed devices.

Apply Power

Once all wiring is complete, and the equipment is secured to the building structure with at least two screws, apply power to the control panel:

- Connect the battery leads to the battery.
- Connect the AC transformer.
- For more information on control panel power specifications, see the PowerSeries Neo Reference manual.

Program the Keypad

- Press [F8][Installer Code]
- Use the [-] keys to navigate through the menus or jump directly to a specific section by entering the section number.
- Programming consists of toggling on and off options in each section or by rotating data fields. Toggle options are enabled or disabled by pressing the corresponding number on the keypad, for example, to enable toggle options 1 and 4, press the [1] and [4] keys. All enabled options are displayed on the following diagram.
- To input data, use the [-] keys to select a character then press the keypad button for the number/letter.
- Using the [-] keys, scroll to the next character and repeat the process. For information on entering HEX data, refer to the PowerSeries Neo Reference manual.

This section is used to change the slot number in which a module is enrolled. To change the slot number:

- Enter [902][002] or use the [-] keys and press [F].
- Enter the serial number of the module.

Program Labels (LCD keypads)

- Press [F8][Installer Code]
- Press [F] and use the [-] keys to scroll to Zone Labels and press [F] again. The first zone is displayed. Alternatively, enter [900][001]
- Use the [-] keys to scroll to the zone label to be programmed and press [F] or enter the zone number (e.g., 001, for zone label 1).
- Use the [-] keys to scroll to the desired character's location, using the [-] keys.
- Press the number of the character until the desired character is displayed (see the following table). Example, press the "2" key three times to enter the letter "2". Press the "2" key four times to enter the number "2". Press [F], then scroll to "Save". Press [F] again to save the label. To delete a character, use the [-] keys to move the cursor under the character, then press [0]. If any key other than [-] is pressed before [0], the cursor moves one space to the right and deletes that character.

CHANGE CASE – Will toggle the next letter between between upper case (A, B, C, ...) and lower case letters (a, b, c, ...).

ASCII ENTRY – Used to enter uncommon characters. Valid entries range from 000 to 255. Use the [-] keys to scroll through the characters or enter a 3-digit number from 000-255. Press [F] to enter the character into the label.

CLEAR TO END – Clears the display from the character where the cursor was located to the end of the display.

POWER LED DISPLAY – Clears the entire label.

Continue from Step 2, until all labels are programmed.

Label Library

The Label Library is a database of words commonly used when programming labels. Individual words can be combined as needed (e.g., Front + Door). Each line of the display shows a maximum of 14 characters. If a word will not fit on a line, scroll right until the cursor appears at the first character of the word. To program a custom label using the Label Library:

- Press [F8][Installer Code][000][001].
- Enter [001] to program the label for zone 01, or use the [-] keys to scroll to the Zone Labels and then press [F]. The current label name is displayed for that zone.
- Press [F] to open the menu.
- Press [F] again to select the "Word Entry" option.
- Enter the 3-digit number corresponding to a word (see Words Library) or use the [-] keys to view words in the library.
- Press [F] to select the word.
- To add another word, repeat the previous procedure from step 3.
- To delete a word, press the right scroll key [F].
- Press Tag Does Not Arm/Disarm or Clear Display* from the menu.
- To save the current label and exit, press [F].

Broadband LCD Labels

If more than one LCD keypad is present on the system, labels programmed on one keypad will be broadcast to all other LCD keypads, after the change is confirmed.

Change Brightness/Contrast/Buzzer

LCD Keypads

- Press [F6][Master Code].

[011] Keypad Input/Output Programming

Zone / PGM Number Default 000

[012] Local PGM Output Pulse Activation Time

Minutes (00-99) Seconds (00-99)

[021] First Keypad Options

- | | |
|--|-----------------------------|
| ON | OFF |
| 1 Fire Key Enabled | Fire Key Disabled |
| 2 Medical Key Enabled | Medical Key Disabled |
| 3 Panic Key Enabled | Panic Key Disabled |
| 4 Display Access Code When Programming | Display Xn When Programming |

NOTE: For EN50131-EN50133 compliant systems, display [021] options 1 and 2 shall be OFF.

[022] Second Keypad Options

- | | | |
|--------------------------------|----------------------------------|-----|
| Default | Opt. | OFF |
| 1 Local Clock Display ON | Local Clock Display OFF | |
| 2 Local Clock Displays 24-hr | Local Clock Displays AM/PM | |
| 3 Auto Alarm Mem Scroll ON | Auto Alarm Mem Scroll OFF | |
| 4 For Future Use | For Future Use | |
| 5 Power LED Enabled | Power LED Disabled | |
| 6 Power LED AC Present ON | Power LED AC Present OFF | |
| 7 Alarms Displayed While Armed | Alarms Not Displayed While Armed | |
| 8 Auto-Scroll Open Zones ON | Auto-Scroll Open Zones OFF | |

[023] Third Keypad Options

- | | | | |
|-----------------------------------|----------------------------------|----|-----|
| Default | Opt. | ON | OFF |
| 1 Armed LED Power Save | Armed LED Off in Sleep Mode | | |
| 2 KeyPad Status Shows Stay Arm | KeyPad Status Shows Stay/Alarm | | |
| 3 5th Terminal is PGM Output | 5th Terminal is Zone Input | | |
| 4 Prox Tag Will Arm/Disarm | Prox Tag Does Not Arm/Disarm | | |
| 5 Local Display of Temperature | No Local Display of Temperature | | |
| 6 Low Temperature Warning Enabled | Low Temperature Warning Disabled | | |

[030] Downloaded LCD Message

NOTE: Clock display (Section [022], Option 1) must be enabled.

[031] Downloaded LCD Message Duration

Default: 000 (Valid entries are 000-255, 000=Unlimited Msg Display)

This number represents the number of times the downloaded message must be cleared before it is permanently downloaded. This message can be cleared by pressing any key.

[041] Indoor Temperature Zone Assigning

Default: 000 (Valid entries are 000-128)

Table 1: Compatible Devices

Wireless PG smoke detector	PGS26UL
Wireless PG smoke and heat detector	PGS916UL
Wireless PG CO detector	PGS913
Wireless PG PIR motion detector	PGS904/PJUL
Wireless PG PIR + camera motion detector	PGS934/PJUL
Wireless PG curtain motion detector	PGS924UL
Wireless PG dual tech motion detector	PGS984/PJUL
Wireless PG mirror motion detector	PGS974/PJUL
Wireless PG outdoor motion detector	PGS954UL
Wireless PG glass break detector	PGS912
Wireless PG shock detector	PGS935UL
Wireless PG flood detector	PGS985UL
Wireless PG temperature detector (indoor)	PGS905UL
Outdoor temperature probe (requires PGM05)	PGTEMP-PROBE
Wireless PG key	PGS991UL
Wireless PG panic key	PGS920UL
Wireless PG panic key	PGS938UL
Wireless PG 2-button key	PGS948UL
Wireless PG indoor siren	PGS901UL
Wireless PG outdoor siren	PGS911UL
Wireless PG repeater	PGS920UL
Wireless PG door/window contact	PGS975UL
Wireless PG door/window contact	PGS945UL

NOTE: In this chart, x in the model number represents the operating frequency of the device as follows: 9 (912-919 MHz), 8 (868MHz), 4 (433MHz).

NOTE: Only models operating in the band 912-919 MHz are ULULIC or cUL listed where indicated. Only UL approved devices are to be used with ULULIC listed systems.

Mount the Keypad


Mount the keypad where it is accessible from designated points of entry and exit. Once a dry and secure location has been selected, perform the following steps to mount the keypad.

Disassemble Keypad

Insert the tip of a flat-head screwdriver into the slots at the bottom left and right of the keypad. Gently pry open the faceplate. This will remove it and allow access for mounting.



Mount and Wire Keypad



- Secure keypad to wall using mounting holes. Use all four screws provided unless mounting on a single gang box. Use the plastic anchors supplied if the unit is to be mounted on drywall.
- If using the keypad tamper, secure the tamper plate to the wall with a screw.
- NOTE: For ULULIC listed commercial burglary installations, the use of the keypad tamper is mandatory.
- Run wire through wiring slot or knockouts. Connect Corbus and PGM/Zone wiring to keypad. Place tamper switch into tamper hole on backplate.
- Place keypad into backplate, ensuring the wire is pushed back into the wall as much as possible. Route the wire inside the keypad, ensuring high components are avoided. Snap the front assembly closed, ensuring that there is no pressure to the keypad from the wire below.
- NOTE: If any tension is found between the front keypad assembly and the wiring, open the keypad, reroute the wire and close again. Repeat these steps until the keypad is closed properly.

Wiring

- Before wiring the unit, ensure that all power (AC transformer and battery) is disconnected from the control panel.
- Connect the four Corbus wires (Red, Black, Yellow, Green) to the keypad terminals. If programmed as an input, a device such as a door contact, may be connected to the P/Z terminal of the keypad. This eliminates the need to run wires back to the control panel.

HS2LED/HS2ICON(P)(RF)/X/HS2LCD(RF)(P)(X)

RED — R (R)
BLACK — B (B)
YELLOW — Y (Y)
GREEN — G (G)
Zone or P/Z output

3. When prompted, enter the new two-digit slot number. The previous slot assignment is replaced with the new one. An error tone sounds if an invalid slot number is entered.

[902][003] – Module Slot Assignment (LCD Only)

Similarly to [002], this section is also used to change the slot number of a module. With this option, however, the serial number is not required. To change the slot number:

- Enter [902][003] or use the [-] keys and press [F].
- Use the [-] keys to scroll to the applicable keypad.
- Press [F] to select the module and when prompted, press [F] again to delete it.

[902][011] Unenroll Keypads

- Enter [902][011] or use the [-] keys and press [F].
- Use the [-] keys to scroll to the specific keypad to delete.
- Press [F] to select the module and when prompted, press [F] again to delete it.

[903][011] Confirm Keypad

To confirm the enrollment of individual keypads and to locate them physically:

- Enter [903][011] or use the [-] keys and press [F].
- Enter [903][011] or use the [-] keys and press [F].
- At each keypad installed on the system:

The keypad must be assigned to a partition if supervision or keypad zones are required. Keypad assignments and keypad option programming must be done at each keypad individually.

Assign a Partition to the Keypad

- Press [F8][Installer Code]
- Enter [861][876] for Keypad Programming and Keypad Partition Mark
- Press [F] for partition assignment.
- Enter 01 to 08 for partition assignment or use the [-] keys to scroll to the specific partition if partitioning is not used, enter [0].
- Press [F] twice to exit programming.
- Continue this procedure for each keypad until all have been assigned to the correct partition.

[861]-[876] Keypad Programming Sections

[861] Address of Partition

A 2-digit entry is required to assign the keypad to a partition. Valid entries are 00-32. NOTE: LED and ICON keypads must not be assigned as global keypads.

[861][005] Keypad Function Key Programming

To program a function key: Press [F8][Installer Code]

- Enter [861][876] for keypad programming.
- Enter [001][005] for function keys 1-5 or use the [-] keys and press [F].
- Enter a 2-digit number to assign a function key option - [001]-[008]. See the following table.
- Press [F] to save the keypad programming.
- Press [F] twice to exit Installer Programming.

Table 3: Function Key Assignment

Function Key	Button	Valid Range	Default	Function
[001]	Key 1	00-68	03	Stay Arm
[002]	Key 2	00-68	04	Away Arm
[003]	Key 3	00-68	06	Chime ON/OFF
[004]	Key 4	00-68	22	Command Output 2
[005]	Key 5	00-68	16	Quick Exit

Keypad Function Keys

Refer to your system installation manual for a complete list of available function key options.

- 01 - Null
- 02 - Instant Stay Arm
- 03 - Stay Arm
- 04 - Away Arm
- 05 - [F9] No-Entry Arm
- 06 - [F4] Chime ON/OFF
- 07 - [F6] [F4] System Test
- 09 - Night Arm
- 12 - Global Stay Arm
- 13 - Global Away Arm
- 14 - Global Disarm
- 16 - [F0] Quick Exit
- 17 - Arm Interior
- 21 - [F9] No-Entry Arm
- 22 - [F7][F] Command Output 2
- 23 - [F6] [F4] System Test
- 24 - Alarm Memory
- 29 - Bypass Group Recall
- 31 - Local PGM Activation
- 32 - Bypass Mode
- 33 - Bypass Recall
- 34 - User Programming
- 35 - User Functions
- 37 - Time & Date Program
- 40 - Alarm Memory
- 41 - Partition Select 1-8

[861][005] Keypad Function Key Programming

To program a function key: Press [F8][Installer Code]

- Enter [861][876] for keypad programming.
- Enter [001][005] for function keys 1-5 or use the [-] keys and press [F].
- Enter a 2-digit number to assign a function key option - [001]-[008]. See the following table.
- Press [F] to save the keypad programming.
- Press [F] twice to exit Installer Programming.

Table 3: Function Key Assignment

Function Key	Button	Valid Range	Default	Function
[001]	Key 1	00-68	03	Stay Arm
[002]	Key 2	00-68	04	Away Arm
[003]	Key 3	00-68	06	Chime ON/OFF
[004]	Key 4	00-68	22	Command Output 2
[005]	Key 5	00-68	16	Quick Exit

Keypad Function Keys

Refer to your system installation manual for a complete list of available function key options.

- 01 - Null
- 02 - Instant Stay Arm
- 03 - Stay Arm
- 04 - Away Arm
- 05 - [F9] No-Entry Arm
- 06 - [F4] Chime ON/OFF
- 07 - [F6] [F4] System Test
- 09 - Night Arm
- 12 - Global Stay Arm
- 13 - Global Away Arm
- 14 - Global Disarm
- 16 - [F0] Quick Exit
- 17 - Arm Interior
- 21 - [F9] No-Entry Arm
- 22 - [F7][F] Command Output 2
- 23 - [F6] [F4] System Test
- 24 - Alarm Memory
- 29 - Bypass Group Recall
- 31 - Local PGM Activation
- 32 - Bypass Mode
- 33 - Bypass Recall
- 34 - User Programming
- 35 - User Functions
- 37 - Time & Date Program
- 40 - Alarm Memory
- 41 - Partition Select 1-8

[042] Outdoor Temperature Zone Assignment

Default: 000 (Valid entries are 000-128)

[101]-[228] Door Chime for Zones

The keypad can be programmed to make up to four different chime sounds for individual zones. (e.g., for Zone 1, enter section [01], for Zone 2 enter section [02]).


- 03 Bings
- 04 Alarm Tone (48 duration)
- 05 Ding dang tone
- 06 Zone Name

[991] Reset Keypad Programming to Factory Defaults

- Press [F8][Installer Code]
- Use the [-] keys to scroll to the applicable keypad.
- Press [F] to select the keypad.
- Press [F] to reset the keypad to factory defaults.
- Press [F] twice to reset the selected keypad to factory defaults.

Keypad Symbols

4: Keypad Display Symbols



1 Memory – Indicates that alarms are in memory.

2 Fire – Indicates that fire alarms are in memory.

3,4,5 Clock Digits – These digits indicate the hour and minutes when the local clock is active, and also identify the zone when the OPEN or ALARM zones are active. These digits scroll one zone per second from the lowest zone number to the highest when scrolling through zones.

6 Bypass – Indicates that there are zones automatically or manually bypassed.

7 Open – When zones are opened, this icon will turn on and the open zones are displayed.

8 Program – If the system is in Installer's or User's Programming, or the keypad is busy, this icon flashes. If an access code is required while accessing star menus, this LED is on steadily to indicate that the code is required.

9 Chime – Turns on when Door Chime is enabled and off when Door Chime is disabled.

10 Away – Indicates that the panel is armed in away mode.

11 Stay – Indicates that the panel is armed in stay mode.

12 Night – Indicates that the panel is armed in night mode.

13 Ready Light (Green) – If the Armed Light (red) is on, the system is ready for arming.

14 Ready Light (Green) – If the Armed Light (red) is on, the system has been armed successfully.

15 System Trouble – Indicates that a system trouble is active.

16 Program – Indicates that AC is present at the main panel.

17 AC – Indicates that AC is present at the main panel.

Proximity (Prox) Tags Support (HS2ICNP/HS2ICNRF/HS2LCDP)

If the prox tag is invalid, the prox tag normally require a user access code or to activate a programmable output. Present the tag to the tag reader (R) or to the left of the keypad LCD.

Assign Proximity Tags

- Using an LCD keypad:
- 1. Press [F5][Master/Supervisor Code].
- 2. Enter a 4-digit user code.
- 3. Press 2.
- 4. Pass the enrolled tag near the tag reader on the keypad.

Delete Proximity Tags

To delete a prox tag, select the user as outlined previously. Swipe the associated prox tag. The alarm system recognizes the tag. Press [F] to delete when prompted.

LED Bar

On the HS2ICNP/HS2ICNRF/HS2LCDP keypads, a blue LED bar indicates that a prox tag is approaching.

The LED bar flashes three times when a valid prox tag is being read by the keypad. If the prox tag is invalid, the LED bar stays on steady and the keypad displays an error tone.

The brightness of the LED bar is adjustable from the [F6] menu. When the keypad brightness is modified, the LED bar brightness is changed accordingly.

Downloading

The HS2LCD(RF)/HS2ICNRF keypad can be programmed over DLS V. This auto-detects the keypad type and downloads programming accordingly.

Wireless Device Setup and Programming (HS2ICNRF(P)(X)/HS2LCDRF(P)(X))

This section describes how to enroll and program wireless devices such as contacts, motion sensors and sirens on the alarm system.

[804][001] Enroll Wireless Devices

Once the HSM2HOST is installed and enrolled on the alarm panel wireless devices can be enrolled using the following method: Enter Installer Programming section [804][001].

- When prompted, either activate the device (see device installation sheet) or enroll immediately or enter a device ID number. Do the latter to pre-enroll devices then enroll them later at the customer site.
- The alarm panel determines the type of device being enrolled and presents the appropriate programming options.

[804][802] Wireless Supervision Window

This option is used to program the length of time a wireless device can be absent from the system before an alarm is generated. Enter Installer Programming section [804][802].

- NOTE: For EN installations, 1 hour or 2 hours must be selected.
- When option 06 is used, which configures the system to generate fault conditions after a device has been detected as absent for 24 hours, smoke detectors generate a fault condition after a maximum of 18 hours from the 20th supervision window. If the supervision window is disabled.

To program the Wireless Supervision Window:

- Enter Installer Programming section [804][802].
- Select one of the following options by scrolling or entering the hotkey:

Table 8: Wireless Supervision Window Options