



Neo Panel Model Differences

	HS2128	HS2064	HS2032
Hardwired Zones	128	64	32
Onboard Zone Inputs	8	8	8
Wireless Zones	128	64	32
Partitions	8	8	4
Users	95	95	72
Onboard Outputs	4	4	2
Max Outputs	148	80	38
Keypads	16	8	8
Wireless Keys	32	32	32
Wireless Sirens	16	8	8
Wireless Repeaters	8	8	8
Proximity Tags	94	94	71
Alt Comm. Phone #s	4	4	4
User Programmable Phone #s	8	8	8
Event Buffer	1000	500	500
8 Zone Expander HSM2108	15	7	3
Power Supply HSM2300	4	3	3
Power Supply/High Current Output Expander HSM2204	4	3	1
8 Output Exp. HSM2208	16	8	4
2 Way Wireless Int. Mod.	1	1	1
Audio Verification Module HSM2955	1	1	1