



4MP Outdoor Floodlight Camera (ADC-V729/V729AC/VC729P) - Junction Box Installation Guide

The junction box mounting accessory for the 4MP Outdoor Floodlight Camera (ADC-V729/V729AC/VC729P) delivers greater install flexibility across various surfaces. The junction box fits between the camera base and the wall for a secure, watertight seal. It can be ordered from the Partner Portal via SKU: ADC-VACC-729-JB.

For more information about installing the camera, see [4MP Outdoor Floodlight Camera \(ADC-V729/V729AC/VC729P\) - Installation Guide](#).

Note: The junction box is designed to be installed on a flat wall/ceiling surface.

To install the junction box:

Important: Prior to installation, verify the wall or ceiling can support the combined weight of the junction box and the camera.

1. Drill holes and mount the junction box to the wall with the included wall screws. If necessary use the included anchors for additional support. If mounting on an exposed wall, verify the conduit hole is on the bottom.



2. Mount the mounting bracket (included with the 729) to the junction box with the included screws.



3. Route and plug in 729 wires.

Note: For more information about how to plug in the wires, see [Wire, mount, and power the ADC-V729/V729AC/VC729P](#).

4. Attach camera to mounting bracket. Ensure both screws are firmly screwed in to ensure tight seal.

