

ALULA HARDWARE SETUP GUIDE FOR Connect+



Follow these steps BEFORE POWERING UP THE DEVICE

If you are not a registered dealer with Alula, please visit www.Alula.net/newdealer to register, or call 1.888.88.Alula.

You must first register the customer and device on alarmdealer.com

Once logged in to AlarmDealer.com, Choose “Create Account Wizard” and begin the 4-step account creation process

1. Create Account

Enter your customer’s information such as Username, Password and vital information.

2. Register Hardware

Add device ‘Friendly Name’. i.e. “Smith Home”

Enter MAC ID found on Helix device

3. Notification Setting

Set customer’s notification preferences


4. Central Station

Add Central Station connection type, Caller ID number, and account number

Select billing features

Follow instructions on reverse side BEFORE POWERING UP THE DEVICE

1 PLUG INTO DESIRED LOCATION TO POWER




POSSIBLE LOCATIONS:

LIVING ROOM
KITCHEN

HOME OFFICE
CLOSET

2 CONNECT CABLE OR JOIN WPS

IF ETHERNET: ATTACH ETHERNET TO HELIX & ROUTER THEN PLUG INTO DESIRED LOCATION



IF WIFI: PRESS WPS BUTTONS ON BOTH HELIX AND CUSTOMER'S ROUTER

3 CHECK LEDs

- POWER: GREEN BLINKS RAPIDLY
- NETWORK CONNECTIVITY: GREEN WHEN CONNECTED
- CENTRAL STATION CONNECTIVITY: GREEN WHEN CONNECTED
- PLATFORM CONNECTIVITY: GREEN WHEN CONNECTED
- ARMING STATUS: GREEN: DISARMED RED: ARMED
- TROUBLE-AMBER: SYSTEM TROUBLE IS DETECTED
- RF ACTIVITY: BLINKS RAPIDLY WHEN ANY SENSORS ARE COMMUNICATING UNUSED

4 DOWNLOAD AND USE APPS FOR INSTALL AND CONTROL

