



ASSEMBLY/ INSTALLATION INSTRUCTIONS, 2 OR 4 LEG BARRIERS



2 LEG BARRIER

1. SB-AC-1624 SHOWN.
2. MUST BE ATTACHED TO SURFACE.
3. SEE SHEET 2 FOR ASSEMBLY INSTRUCTIONS.
4. SEE SHEET 4 FOR INSTALLATION INSTRUCTIONS .
5. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832 MODELS.

4 LEG BARRIER

1. SB-AC-1624 SHOWN.
2. CAN BE FREE STANDING (NO ATTACHMENT).
3. SEE SHEET 3 FOR ASSEMBLY INSTRUCTIONS.
4. SEE SHEET 5 FOR INSTALLATION INSTRUCTIONS.
5. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832 MODELS.

KENDALL HOWARD CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KENDALL HOWARD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF KENDALL HOWARD IS STRICTLY PROHIBITED.	UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. TOLERANCES: FRACTIONAL: ±1/8 ANGULAR: ±1° TWO PLACE DECIMAL: ±.03 THREE PLACE DECIMAL: ±.010 HOLE: ±.005		APPROVAL DRAWN BS 05/08/2020 DESIGN BS 05/12/2020 ENG APPR MFG APPR	DATE 05/08/2020 05/12/2020	KENDALL HOWARD INSTRUCTIONS, ASSEMBLY/ INSTALLATION- COUGH/ SNEEZE SHIELD
	MANUFACTURING COMMENTS: New assbly/ installation instruction document.	MATERIAL: NA SURFACE AREA (in ²): FINISH ID: NA FINISH DESCRIPTION: NA	LEGACY Part Number: CLASSIFICATION: Reference Document	SIZE DWG. NO. REV A A-1260 A	
ECO No: N/A Description: Initial Release By: BS Date: 05/12/2020 App By: -	DO NOT SCALE DRAWING		THIRD ANGLE PROJECTION 	INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5-2009	SCALE: 1:8 WEIGHT (lbs): SHEET 1 OF 5

D
C
B
A

D
C
B
A



5 4 3 2 1

5 4 3 2 1

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	NA	ACRYLIC PANEL WITH 10"X3" CUTOUT	1
2	A-1184	RIGHT BARRIER FOOT - 10 X 21.5	1
3	A-1193	LEFT BARRIER FOOT - 10 X 21.5	1
4	A-1196	BACKER STRIP - 4 HOLE	2
6	hw-ths-002	SCREW, TRUSS HEAD, 10-32 X .500 LG	8


2 LEG ASSEMBLY INSTRUCTIONS

1. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832.
2. SCREW TORQUE MAXIMUM 10 in-lb.
3. TOOLS REQUIRED: NO. 2 PHILLIPS SCREWDRIVER.



KENDALL HOWARD 


SIZE	DWG. NO.	REV
A	A-1260	A
SCALE: 1:8	WEIGHT (lbs):	SHEET 2 OF 5



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	NA	ACRYLIC PANEL WITH 10"X3" CUTOUT	1
2	A-1184	RIGHT BARRIER FOOT - 10 X 21.5	1
3	A-1193	LEFT BARRIER FOOT - 10 X 21.5	1
4	A-1186	LEFT BARRIER FOOT - 4 X 21.5	1
5	A-1195	RIGHT BARRIER FOOT - 4 X 21.5	1
6	A-1196	BACKER STRIP - 4 HOLE	2
8	hw-fhs-002	SCREW, TRUSS HEAD, 10-32 X .500 LG	8


4 LEG ASSEMBLY INSTRUCTIONS

1. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832.
2. SCREW TORQUE MAXIMUM 10 in-lb.
3. TOOLS REQUIRED: NO. 2 PHILLIPS SCREWDRIVER.




KENDALL HOWARD

SIZE	DWG. NO.	REV
A	A-1260	A
SCALE: 1:8	WEIGHT (lbs):	SHEET 3 OF 5




VHB TAPE INSTALLATION INSTRUCTIONS, 2 OR 4 LEG BARRIERS



2 LEG BARRIER

1. SB-AC-1624 SHOWN.
2. VHB TAPE IS SUPPLIED.
3. LOCATE VHB TAPE APPROXIMATELY SHOWN.
4. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832 MODELS.



4 LEG BARRIER


1. SB-AC-1624 SHOWN.
2. VHB TAPE IS SUPPLIED.
3. LOCATE VHB TAPE APPROXIMATELY SHOWN.
4. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832 MODELS.

NOTE:


1. CLEAN SURFACE(S) THAT ARE BEING MOUNTED TO AND LEGS WITH SOLVENT AND WIPE DRY.
2. REMOVE LINER FROM ONE SIDE OF THE VHB TAPE AND FIRMLY PRESS IN PLACE, APPROXIMATELY AS SHOWN. REPEAT FOR OTHER LOCATIONS. SHOWN.
3. REMOVE VHB TAPE LINER FROM ATTACHED TAPE. LOCATE SHIELD AND FIRMLY PRESS IN PLACE.

KENDALL HOWARD 

SIZE	DWG. NO.	REV
A	A-1260	A
SCALE: 1:8	WEIGHT (lbs):	SHEET 4 OF 5




HARDWARE INSTALLATION INSTRUCTIONS, 2 OR 4 LEG BARRIERS



2 LEG BARRIER

1. HARDWARE IS NOT SUPPLIED.
2. SHOWN IS MINIMUM REQUIRED HARDWARE FOR MOUNTING.
3. FOR SURFACES THINNER THAN 1.00" USE #10 OR #8 X 1.25" LONG SCREW WITH FLAT WASHER AND NUT. DRILL 7/32" HOLE.
4. FOR SURFACES THICKER THAN 1.00" USE #8 WOOD SCREW OR #6 SHEET ROCK SCREW, 1.00" LONG
5. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832 MODELS



4 LEG BARRIER

1. HARDWARE IS NOT SUPPLIED.
2. SHOWN IS MINIMUM REQUIRED HARDWARE FOR MOUNTING.
3. FOR SURFACES THINNER THAN 1.00" USE #10 OR #8 X 1.25" LONG SCREW WITH FLAT WASHER AND NUT. DRILL 7/32" HOLE.
4. FOR SURFACES THICKER THAN 1.00" USE #8 WOOD SCREW OR #8 SHEET ROCK SCREW, 1.00" LONG
5. TYPICAL FOR SB-AC-1618 THRU SB-AC-4832 MODELS

KENDALL HOWARD 

SIZE	DWG. NO.	REV
A	A-1260	A
SCALE: 1:8		WEIGHT (lbs):
		SHEET 5 OF 5



THIRD ANGLE PROJECTION
INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5-2009