PPIX L License Plate Recognition IP Camera

DWC-MB45iALPRTW Ma

Test Video Cable		1	(Black: ø0.15" (ø4mm), White: ø0.19" (ø5mm)		1 set
NOTE: Download all your s	upport materials a	nd tools	n one place		
	entering the part le part numbers w orted materials, inc	number i vill popula cluding m	n the 'Search by Product' search te automatically based on the anuals	DW	
			uick reference for the initial set-u omplete and proper installation a		ided
SAFETY AND W. Read through this Installatio			MATION Installing the product. Keep the In	nstallation Guide f	or future

- reference. See the user manual for more information on the proper installation, use and care of the product.
- These instructions are intended to ensure that users can use the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected. Cautions: Injury or equipment damage may occur if any of the cautions are neglected. INTING
 In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.

 Be sure to use only the standard adapter specified in the specification sheet. Using any other adapter could cause fire, electrical shock, or damage to the product.

 Make sure the power supply voltage is correct before using the camera.

 Incorrectly connecting the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product.

 Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat generation or fire. 5. securely plug the power cord into the power source. An insecure connection may cause a fire 6
- When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.

 Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or electric shock. 8. 9.
- Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.

 Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.

 Do not install near any heat sources such as radiators, heat registers, or other products (including amplifiers) that produce heat.

 Keep out of direct sunlight and heat radiation sources. It may cause a fire. 11. 13.
- If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way. When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock Use proper safety gear when installing and wiring the product.

 Do not drop objects on the product or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference.

 Do not use this product near water. 2.
- 10. point where they exit from the product. If any laser equipment is used near the product, make sure the surface of the sensor is not exposed to the laser 11. beam as that may damage the sensor module
- 18. 19. Onplug this product when a cart is used. Ose caution when moving the cart product combination to avoid injury from tip-over.
 Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

STEP 1 - PREPARING TO MOUNT THE CAMERA

operating instructions unless you are qualified to do so.

STEP 2 - POWERING THE CAMERA

Pass the wires through and make all necessary connections.

the wall or ceiling.

Adapter not Included.

Use a PoE Switch or PoE Injector

This product is intended to be supplied by a UL Listed Power Supply Unit marked "Class 2" or "LPS" or "PS2" and rated 12 Vdc, 0.75A min. 3. The wired LAN hub providing power over the Ethernet (PoE) in accordance with IEEE 802-3af

CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the

to connect data and power to the using and Ethernet cable and use a camera using a single Ethernet cable. power adapter to power the camera.

Use non-PoE Switch to connect data

Recorder

NOTE: To ensure moisture seal, make sure the o-ring is in place between a and 5. In extreme environments use of an outdoor rated sealer is recommended.

Camera

network cable's diameter.

Camera Recorder

Mount the camera to the mounting surface and secure using the screws and anchors NOTE: It is recommended to position a license plate or vehicle to reflect the IR light of

the camera) to sequentially zoom and auto-focus the camera. Alternatively, the camera's web GUI or management software can be utilized as well. The longer the Zoom Lens button (T-W jog button) is pressed down, the further the lens module will zoom. Please note that the cameras ship with the focus in Manual mode. To change the camera's

camera and the mounting surface.

a poor quality image of moving license plates.

while adjusting the camera's focus on the target area.

LPR INSTALLATION GUIDELINES

(vertically) from the target area.

Reset 6

input

button

Zoom

buttor Test video output

THE CAMERA SHOULD BE MOUNTED AT AN ANGLE NO GREATER THAN 30 DEGREES

11.5ft

6 Alarm In

Audio Out

NOTE: Based on the installation, remove the rubber plug on the side of the camera's bracket for a cable guide to prevent cables from getting caught between the

The LPR camera should be mounted at a height between 3-8 ft., and a distance no greater than 80 ft. from the target area. Exceeding the distance recommendations may result in

Ensure that the camera angle is no more than 20° degrees (horizontally) and 30° degrees

It is recommended to position a license plate or vehicle to reflect the IR light of the camera

After mounting the camera, you can press the Zoom Lens Button (located on the underside of

Alarm Out Network

Audio In

1. Locate the SD card slot at the bottom of the camera by unscrewing the con cap.

2. Insert a class 10 SD/SDHC/SDXC card into the SD card slot by pressing the SD card until

3. Press the card inward until it clicks to release from the card slot then pull it out from the

When inserting the SD card into the card slot, the SD card's contacts should

Power

STEP 5 - MANAGING THE SD CARD

NOTE: Maximum SD Card size supported: 64GB.

be facing upward, as shown in the diagram.

Ping camera Bulk password Camera's name, IP and MAC addresses WATCHDOG **Network Setup** To install the DW IP Finder, go to: http://www.digital-watchdog.com 1. Enter "DW IP Finder" on the search box at the top of the page. Go to the "Software" tab on the DW IP Finder page to download the installation file and follow the installation instructions. 4. Open the DW IP Finder and click 'Scan Devices' to scan the selected network for all supported devices. Results are in the table. During the scan, the DW® logo will turn gray. 5. When connecting to the camera for the first time, a Bulk Password Assignment password must be set. To set up a password for your camera: a. Check the box next to the camera in the IP Finder's search results. You can select multiple cameras. b. Click "Bulk Password Assign" on the left.

STEP 7 - WER VIEWER

ASPH-829

5. When accessing the camera for the first time, install the VLC player for web files to view video from the camera. *(* http://192.168.10.159/ - IP Camera - Internet Explorer

Change admin's password

NOTE: Some menu options may not be available based on the camera model. See the

NOTE: Please see the full product manual for web viewer setup, functions and

[Type the Password] Password requirement: minimum 8 characters with at least three combinations of uppercase letters, lowercase letters, numbers and special characters. Acceptable special characters are; $\sim 1\$ ()_- |\{\}];$. ? /

- 14.
- on the product 5.
- image sensor.

 The Main plug is used as a disconnect device and shall stay readily operable at any time.

 Remove the power adapter from the outlet when there is lightning. Neglecting to
- The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the 6.
- o do so may cause fire or damage to the product.

 Do not block any ventilation openings. Install following the manufacturer's instructions.

 A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.

 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the paint where they with from the product. If you want to move the already installed product, be sure to turn off the power and then move or reinstall it. Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user. 14.
- fi cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.

 Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device 15. Use only attachments/accessories specified by the manufacturer Always use hardware (e.g. screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount.

 Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product.

 Unplug this product when a cart is used. Use caution when moving the cart/product combination to avoid injury from the over. 17.
- shall be a UL Listed device with the output evaluated as a Limited Power Source as defined in UL60950-1 or PS2 as defined in UL62368-1. 4. Unit is intended for installation in a Network Environment 0 as defined in IEC TR 62102. As such, associated Ethernet wiring shall be limited to inside the building.

5. Using the mounting template sheet or the camera itself, mark and drill the necessary holes in

PoE Max 10.5W

- NOTE: Cables with $\emptyset 4.5$ mm to $\emptyset 5.5$ mm thickness should use the black rubber ring. Cables over Ø5.5mm in thickness should use the white rubber ring.
- WATERPROOF CAP INSTALLATION The waterproof cap set comes with two rubber rings. Use the rubber ring best suited for your

Loosen the pan and tilt screws at the base of the camera's bracket to adjust the camera's view and position. 3. Remove the protective film from the lens cover. Softly wipe the dome/lens cover with lens tissue or a microfiber cloth with ethanol to remove any dust or smudges left from the installation process. Resetting the camera: Open the control board at the bottom of the camera. Press the reset button for five (5) seconds to initiate a camera-wide reset of all the settings, including network settings.

Rubber Plug

focus to Auto, enter the camera's web GUI and use the +/- zoom buttons on the left of the camera image. THE CAPTURED IMAGE SHOULD BE FILLED WITH THE FULL WIDTH OF THE VEHICLES

CAMERA ANGLE NO GREATER THAN 20 DEGREES FOR SIDE MOUNT INSTALLATIONS

< 30°

< 20°

- STEP 6 DW® IP FINDER™ Use the DW IP Finder software to scan the network and detect all MEGApix® cameras, set the camera's network settings or access the camera's web client.
- The camera's IP must be set to static if connecting to Spectrum® IPVMS. Contact your network administrator for more information.

from an external network.

server.

information.

Select DHCP to allow the camera to receive

Select "Static" to manually enter the camera's

its IP address automatically from the DHCP

IP address, (Sub)Netmask, Gateway and DNS

- browser. 4. Enter the camera's username and password you setup in the DW IP Finder. If you did not setup a new username and password via the DW IP Finder, you will not be able to view video from the camera. A message will direct you to setup a new password for the camera to view video.
- Retype Password

- **Power requirements Power consumption** DC12V, PoE (IEEE 802.3af class 3). DC12V Max 9W
 - Recorder Camera
 - STEP 3 INSTALLING THE CAMERA included. See LPR installation guidelines on the next page. the camera while adjusting the camera's focus on the target area.

STEP 4 - CABLING

DI: Yellow + Dot DI COM : Yellow DO1(N.O.) : Blue + Dot DO1 COM : Blue

clicks.

slot.

Use the diagram below to properly connect external devices to the camera. N.O

c. Enter admin/admin for the current username and password. Enter a new username and password to the VC-MF2Wi4T 00:0D:F1:21:66:92 192.168.10.159 right. Passwords must have a minimum of 8 characters with at least 4 combinations of uppercase letters, lowercase letters, numbers and special characters. Passwords cannot contain the user ID. d. Click "change" to apply all changes. Select a camera from the list by double-clicking on the camera's image or clicking on the 'Click' button under the IP Conf. column. The pop-up window will show the camera's current network settings, allowing admin users to adjust the settings as needed. To access the camera's web page, click on the 'View Camera Website' from the IP Config window. 8. To save changes made to the camera's setting, enter the DWC-MD421TIR username and password of the camera's admin account MAC Address 00:0D:F1:20:A4:9E and click 'Apply'. O Static IP IP Address 192.168.1 .101 Default TCP/IP information: DHCP. 255,255,255,0 Netmask Gateway 192.168.1 .1 n Port forwarding must be set in your DNS 192.168.40 .1 network's router to access the camera

> Web Port Control Port

Video Port

Audiio Tran

Audio Receive 0

admin

••••

digital-watchdog.com

- The GUI display may differ by camera models. Find the camera using the DW IP Finder. 2. Double-click on the camera's view in the results table. 3. Press the 'View Camera Website'. The camera's web viewer will open up in your default web

full manual for more information.

Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

camera settings options.

Tel: +1 (866) 446-3595 / (813) 888-9555

Rev: 12/22

- Star Wrench (T-20) **n** @ Waterproof Cap and Rubber Rings

Template

Default Login Information: admin | admin When logging into the camera for the first time, you will be prompted to set up a new password. You can set the new password using the

Quick Start Guide